

### **Merenje frekvencije ne funkcioniše**

The measuring range for the voltage amplitude is retained after switching from voltage to frequency measurement. If voltage amplitude is now outside of the selected range during frequency measurement, 0 Hz appears.