

### **Vrednost displeja se ne vraća na Nulu**

For measurements in the AC or AC+DC range, valid measured values are only read out as of a display value of at least 10% of the measuring range due to the non-linear TRMS converter (e.g. with METRAHIT X-TRA 29S).